



Estado

DashBoard

Nos muestra estadísticas del funcionamiento de nuestra planta **Zycoo**, en esta podemos observar rendimiento de CPU, uso de MEMORIA, espacio en disco, y USB (si tuviéramos agregada alguna USB).



También en podemos encontrar información básica del sistema y una gráfica que nos muestra las llamadas en progreso.



SwitchBoard

Extensiones:

Aquí podemos monitorear si la **extensiones** están registradas y funcionando, la interfaz de **Zycoo** nos muestra si la extension esta registrada, si esta sonando, si esta ocupada, si no esta registrada y si esta en DND (no molestar)

● Idle ? ● Ringing ? ● Busy ? ● Offline ? ● DND ? 📶 Push Notification ?

100 [100]
● Offline

101 [101]
● Offline

102 [102]
● Offline

103 [103]
● Offline

Total : 4 Busy : 0 Idle : 0

Trunks:

Aquí podemos ver el estado de nuestra troncales, tanto si son SIP, IAX, E1, Analógicas.

SIP Trunks				
Trunk Name	Type	Server Address	Reachability(Millisecond)	Status
Vox	Client Mode	sipbilling.voxdatacomm.com	37.738	Rejected
1 Total				

IAX Trunks				
Trunk Name	Type	Server Address	Reachability(Millisecond)	Status
No items to display.				
0 Total				

Analog Lines				
Port	Type	BLF	Status	Channel Status
No items to display.				
0 Total				

Revision #1

Created 16 January 2020 18:39:00 by Eduardo Mejia

Updated 16 January 2020 18:39:27 by Eduardo Mejia